

# Coillte

## **WSX Mobile Solution**


Garmin 780

© 2021 Trimble, Inc - All Rights Reserved - Confidential and Proprietary Information




Login






Please ensure you are logged into the WSX Mobile App every day while you have a Coillte load on-board.


Your TRP's will not work properly if you are not logged in.







#### **Request TRP - New TRP**



## **Request TRP - New TRP (contd.)**

Trimble WSX Mobile - Truck	Driver		🔺 🗢 🗗 🗄
JOBS - 1	MESSAGES - 1		SETTINGS
			<b>  </b> † ]= 🍫 (•)
Waiting for Sa	les Orders for CE02/	H0076	
8			
			<b> </b> ∱≣ 🗞 (•
Please touch h	nere to complete SO	Selection	
11			
Create Job			0 🖬 😣 🗦
	28/07/2021 11:19		•
Truck Company:	AFL - Trimble Forestry		
Truck:	DANT (DANT)	Backload Type:	
	AFL - AFL20 (AFL20)	Permits:	
	🌖 Staging: 🌒	Staging Area:	
Docket: Forest & HU: Customer:	CE02 - H0076 OSB - Smartply Europe L	Unit: Truck & Trai	ler (1/1) 🛛 🔒

<u>)</u>			
eate Job			? ∎ ⊗ >
	28/07/2021 11:19		• •
uck Company:	AFL - Trimble Forestry		
uck:	DANT (DANT)	Backload Type:	
	Please Choose	Permits:	
	🌖 Stagin <mark>y.</mark> 🌗	Staging Area:	
	lease touch here to creat	Unit: Truck & Traile e uplift for this TRP	er (1/1) 🔒
imble WSX Mobile - Truck Drive			🔺 🗢 🕞 🗄
JOBS - 1	MESSAGES - 1	стоск	SETTINGS
			📑 🕂 🗮 🍫 (0)

Please wait for WSX to process the TRP request for CE02/H0076



			?	8
	Truck and Trailer	Docket:	Please Enter	
g:	CF - Coillte			
	CE02 - Maghera			
st Unit:	H0076 - BALLYVROGHAUNC	DUGHTER		
	99			
	002 - OSB (Pulp - SS - 3.00)			
	Pulp			
	OSB - Smartply Europe Ltd			
	P SS 3.0			
lob				⊗
	NT] and Trailer [AFL20] on Bros. Timber Ltd		ate: Wed 28/07/21 11:19 ate: Wed 28/07/21 13:49	
n: CE02/H00			er: DEFAULT - DEFAULT	
	artply Europe Ltd			
P SS 3.0			DISPLAY DIRECTIO	NS
	C	ONFIRM		
			s/N) 🔰 🗄	<b>v</b> (10)
			CONFIRME	D

OSB

3021618


Edit Upl

Log O Forest Harve

CE02/H0076

P SS 3.0

#### **Delete TRP**





#### **Edit TRP**



	8
3022010	
Contractor [AFL]: Truck [DANT] and Trailer [AFL6]	
Thu 29/07/21 19:12	
Thu 29/07/21 20:42	
Maghera - MAGHERA -	
CE02 - H0078	
99	
005 / OSB - Smartply Europe Ltd / Pulp	
OSB - Smartply Europe Ltd	

>

ø

<u> </u>			
Edit Job			? ∎ ⊗ >
	29/07/2021 19:12		• 🕗
Truck Company:	AFL - Trimble Forestry		
Truck:	DANT (DANT)	Backload Type:	No Backload
	AFL - AFL6 (AFL60)	Permits:	
	🍉 Staging: 🌰	Staging Area:	
	3022010 CE02 - H0078 OSB - Smartply Europe Lto P SS 3.0	Unit: Truck & Traile	er (1/1) 🛛 🕓


Edit Up	ift			
			CA	NCEL
5				
Edit Uplift				0 😣 🖬
Unit:	Truck and Trailer	Docket:		
Log Org:	CF - Coillte			
Forest:	CE02 - Maghera			
Harvest Unit:	H0078 - MAGHERA			
	99			
Sales Order:	005 - OSB (Pulp - SS - 3.00)			
	Pulp			
	OSB - Smartply Europe Ltd			
	P SS 3.0			

<u>/</u>			
Job			? ∎ 🔉 >
	29/07/2021 19:12		• 🧹 🔥
ck Company:	AFL - Trimble Forestry		
ck:	DANT (DANT)	Backload Type:	No Backload
	AFL - AFL6 (AFL60)	Permits:	
	🌒 Staging: 🌒	Staging Area:	
	3022010 CE02 - H0078 OSB - Smartply Europe Ltd P OC 3.0	Unit: Truck & Traile	r (1/1) 🔒

<u>/</u>			
Confirm J	ob Submit		
Do you v	ant to sub	mit the Job ch	nanges?
		N	NO YES
			📋 🗄 🇞 (0)
			AT CREW
			3022010



## Weighing Procedure



### Edit TRP (contd.)



## Jobs Statuses

If you are in the correct Forest/Loading Area , you will see a "AT CREW" status

You must contact us before you arrive at the customer if you do not have "LOADED" for your job

Please ensure you are checking this regularly





## Troubleshooting

- Click Apps > Diagnostics which will bring us a Diagnostics Report, all 5 should have a green ticks
- "Restart BT5 Comms" if "Mantle Sync Test" time is not up-to-date
- When logging into the device please enter your user ID & password provided
- Please contact us if you do not have a driver login setup or have forgotten your login details

Vahiala Oceanation Otatus, Oliala farmers info	
Vehicle Connection Status Click for more info	$\odot$
GSM/Internet Connection Connected	
RCOM Server Status Logged In	
Mantle Sync Test 2021-06-02 12:10	
Mantle Connection Status OK	$\odot$
Restart Tablet	Restart BT5 Comms





## Troubleshooting

#### **Contact Details**

Trimble Email: tfl\_galway@trimble.com ORBCOMM Email: fmsupport@orbcomm.com

> Trimble Phone: 091-735728 ORBCOMM Phone: 01-5824013

**Support Hours:** Mon -Fri: 06:00 – 19:00

**Out-of-Hours Emergency Support provided** 




## **Manual Statusing**

#### Loading Area & Destination

#### Attention:

Loading Area does not have an established geofence, manual update of job status required for this stop




In some cases, there is not a geofence setup yet for a forest or destination (e.g. Miscellaneous Customers)

In this case you will be required to manual status yourself when you arrive at the correct location.

#### Attention:

Destination does not have an established geofence, manual update of job status required for this stop



# **Tips & Hints**

- Create your next/first job for the collection day onboard as far in advance of your proceeding into the Forest/Loading Area as is possible recommended minimum of 15 mins before you hit the Forest/Loading Area
- Ensure that you are in good mobile phone reception when you are creating a job onboard
- If you ever need to be on Coillte property without a job/permit onboard, you must notify us in advance of entering the given property by sending us a text on the device





## **Security Alerts**

#### **Types Breach Investigations**



# Security, Geofence & Job Statusing

- A geofence is a virtual perimeter which is linked to GPS-linked mapping data for Coillte properties and customers. It interacts with the GPS antenna with your ORBCOMM device
- It allows us to move your job through the various phases that it needs to go through in order to appear on whatever customer you are going to
- It also serves as part of the Smart Timber Security Package. As your truck passes a geofence around a forest, queries are sent out to your device, ascertaining whether there is a valid job on the system



